



Firmware Release Note

ZyAIR B-2000 v.2

Release 3.50(HF.0)c0

Date:

July 30, 2003

Author:

Postel Chen

ZyXEL ZyAIR B-2000 v.2 Standard Version release 3.50(HF.0)c0 Release Note

Date: July 30, 2003

Supported Platforms:

ZyXEL ZyAIR B-2000 v.2

Versions:

ZyNOS F/W Version : V3.50(HF.0) | 07/29/2003 10:30:00

BootBase : V1.04 | 06/19/2003 10:22:37

Notes:

1. If Wireless Port Control (SMT Menu 23.4) is “Authentication Required”, ZyAIR will enable 802.1x user authentication mechanism, a wireless user must login the ZyAIR successfully before accessing network service. If Wireless Port Control is “No Authentication Required”, ZyAIR will allow all wireless users to access network service. If Wireless Port Control is “No Access Allowed”, ZyAIR will not allow wireless user to access network service.
2. If SMT 23.4 Dynamic WEP Key Exchange is 64-bit WEP/128-bit WEP, Authentication Databases must be RADIUS Only.

Known Issues:

1. WPA is not ready for 3.50(HF.0)c0.
2. CNM Wireless LAN configuration is not ready for 3.50(HF.0)c0.
3. SSL passthrough is not ready for 3.50(HF.0)c0

[CI Command List](#)

Features:

Modification in 3.50(HF.0)b6 | 7/17/2003

1. [FEATURE CHANGED]
Change model name to ZyAIR B-2000 v.2.
2. [FEATURE ENHANCED]
Add RADIUS Accounting attribute – Terminate Cause.
3. [BUG FIXED]
Send EAP-Fail message to supplicant when supplicant's idle timeout expired, etc.
4. [BUG FIXED]
Symptom : Display error in CI command "config display firewall".
Condition : Use CI command type "config disp firewall" ACL set 7 and set8 show LAN/ZyWALL should change to LAN/ZyAIR.

Modification in 3.50(HF.0)b5 | 7/09/2003

1. [BUG FIXED]
Symptoms : Warning message error on eWC set WEP key.
Condition : Use eWC set Wireless WEP key, use 128 bits Hex mode, if user set just set 1 key, it show 28Hex, should change to 26 Hex. And if user just key in one key, please show warning message like "please key in 4 keys".
2. [BUG FIXED]
Symptom:sys reset by cinfofigure NAT rule Condition : Run auto test program to config NAT rule will cause system reset . please refer attach file.

Modification in 3.50(HF.0)b4 | 7/02/2003

1. [BUG FIXED]
Symptoms : Warning message error on eWC set WEP key.
Condition : Use eWC set Wireless WEP key, use 128 bits Hex mode, if user set just set 1 key, it show 28Hex, should change to 26 Hex. And if user just key in one key, please show warning message like "please key in 4 keys".
2. [BUG FIXED]
Symptom : use eWC open NAT port, did not create firewall rule.
Condition : use eWC open set SUA/NAT port, did not open firewall rule.
3. [BUG FIXED]
Symptom : Should login twice to eWC.
Condition : Use eWC to configure B2020, sometime it should login twice.
4. [BUG FIXED]
Symptom : enable the RTS/CTS and Fragmentation show wrong status.
Condition:Use eWC to enable the RTS/CTS and Fragmentation but didn not change value, apply it will reports "Nothing changed; no need to perform save".
5. [BUG FIXED]
Symptom : all configuration reset to orginal value.
Condition : Use eWC set LAN, after change DNS server type will cause other field reset to orginal value.
6. [BUG FIXED]

Symptom : eWC system setup reset to original value.

Condition : In eWC System General setup , after change DNS server type, all other fields setup will reset to original value.

7. [BUG FIXED]

Symptom : Can not set WAN ethernet Toshiba via eWC.

Condition : Ues eWC set WAN as Ethernet and type set Toshiba, Manager, Telstra. when Apply it will get "ERROR : Fail to update due to unternal error (-9)!" error message.

8. [BUG FIXED]

Symptom : When rebooting via SMT menu 24.4.11, the Win XP Telnet hangs - MUST send a RST to the telnet session on reboot.

Condition : When rebooting via SMT menu 24.4.11, the Win XP Telnet hangs - MUST send a RST to the telnet session on reboot. This problem has solved on most ZyWALL devices recently.

9. [BUG FIXED]

Symptom : set roaming cause b2020 crash.

Condition : Use SMT 3.5 set roaming configure, when enable it. B2020 crash.

10. [FEATURE CHANGED]

The LED control is changed, SYS LED will blink with red light when the device is booting and turn green while the device is ready.

11. [BUG FIXED]

Symptom : Modify rom version and check sum fail.

Condition :From debug mode change country code to Japan (EA) or Australia (F4) then upgrade rom file, rom version and check sum fail.

12. [BUG FIXED]

Symptom:sys reset by cinfofigure NAT rule.

Condition : Run auto test program to config NAT rule will cause system reset . please refer attach file.

Modification in 3.50(HF.0)b3 | 6/13/2003

1. [BUG FIXED]

Symptom : mbuf leak problem when using DNS proxy.

Condition : When PC (LAN side) DNS server IP address is LAN IP address.

2. [BUG FIXED]

Symptom : eWC set DNS server fail.

Condition : eWC set LAN DNS, set First DNS = User-Defined and set Servedr IP, then select Second DNS = User-Defined, after web refresh, fiest DNS IP addr = 0.0.0.0.

3. [FEATURE CHANGED]

AP firmware is changed to v.3613 to improve the stability of wireless connection.

Modification in 3.50(HF.0)b2 | 5/30/2003

1. [BUG FIXED]

Symptom : system reboot with SB test.

Condition : Use Smartbits test report, when use 50 Mbps send packet from LAN to WAN, B2020 will reboot.

2. [BUG FIXED]

Symptom : Number of Wireless Stations Allowed reset to 0.

Condition : Use eWC set Wireless, change the value of "Number of Wireless Station Alloewd", reboot system then use eWC set Wireless MAC Filter, the number of "Number of Wireless Station Alloewd"

- will reset to 0.
3. [BUG FIXED]
Symptom:eWC LOGS\Reports function did not work.
Condition : eWC LOGS\Reports function did not work.
 4. [BUG FIXED]
Symptom : SMT 3.2 DNS fail.
Condition : From SMT 3.2 set DNS server, can not apply to DHCP client, from eWC LAN setup check it, the IP address show 0.0.0.0
 5. [BUG FIXED]
Symptom: Handover function doesn't work.
Condition: After the STA roams to another BSS, the STAs in original BSS cannot ping the roamed out STA unless the STA ping the STAs in original BSS first.
 6. [BUG FIXED]
Symptom: Station cannot associate with device while roaming is enabled unless user reset wireless LAN.
Condition: When station is turned on before the roaming enabled device is turned on, the station cannot associate the device unless the user reset the wireless LAN by re-configure the wireless setting or issue “wlan reset”.
 7. [BUG FIXED]
Symptom :Disable Intra-BSS Traffic fail.
Condition : Disable Intra-BSS Traffic fail.
 8. [BUG FIXED]
Symptom : B2020 unable to obtain an IP lease from DHCP server when firewall is enabled.
Condition : Enable firewall, set WAN as Ethernet mode and dynamic get IP address, B2020 can not get IP from DHCP server.
 9. [BUG FIXED]
Symptom : Did not open firewall rule.
Condition : Enable firewall and open NAT port, the service still block by firewall.
 10. [BUG FIXED]
Symptom :SMT 24.1 display version + fail.
Condition :SMT 24.1 displays firmware version as:ZyNOS F/W Version+ V3.50(HF.0)b1 | 5/8/2003 I think the + sign after version should be a :
 11. [BUG FIXED]
Symptom :Enable WEP cause wireless throughput down 30 %.
Condition : Enable WEP cause wireless throughput down 30 %.
 12. [BUG FIXED]
Symptom :Delete keyword button can not work.
Condition : Use eWC firewall set filter , add keyword, press delete button, it ddoes not work.
 13. [BUG FIXED]
Symptoms : Warning message error on eWC set WEP key.
Condition : Use eWC set Wireless WEP key, use 128 bits Hex mode, if user set just set 1 key, it show 28Hex, should change to 26 Hex.
 14. [FEATURE CHANGED]
Wireless default channel is CH06.

Modification in 3.50(HF.0)b1 | 5/8/2003

1. First release for C3 baseline firmware

CI Command List

Command Class List Table		
System Related Command	Exit Command	Ethernet Related Command
Wireless LAN Related Command	IP Related Command	Bridge Related Command
Radius Related Command	802.1x Related Command	

System Related Command

[Home](#)

Command			Description
sys			
	Adjtime		retrive date and time from Internet
	Callhist		
		display	display call history
		remove	<index> remove entry from call history
	countrycode		[countrycode] set country code
	Date		[year month date] set/display date
	domainname		display domain name
	Edit		<filename> edit a text file
	extraphnum		maintain extra phone numbers for outcalls
		add	<set 1-3> <1st phone num> [2nd phone num] add extra phone numbers
		display	display extra phone numbers
		node	<num> set all extend phone number to remote node <num>
		remove	<set 1-3> remove extra phone numbers
		reset	reset flag and mask
	Feature		display feature bit
	hostname		[hostname] display system hostname
	Log		
		clear	clear log error
		disp	display log error
		online	[on off] turn on/off error log online display
	Rn		
		load	<entry no.> load remote node information
		disp	<entry no.>(0:working buffer) display remote node information
		nat	<none sua full_feature> config remote node nat
		nailup	<no yes> config remote node nailup
		save	[entry no.] save remote node information
	Stdio		[second] change terminal timeout value
	systemname		[system name] Change system name
	time		[hour [min [sec]]] display/set system time
	Trcdisp	parse, brief, disp	monitor packets
	Trclog		
	trepacket		
	Syslog		
		server	[destIP] set syslog server IP address
		facility	<FacilityNo> set syslog facility
		type	[type] set/display syslog type flag
		mode	[on off] set syslog mode
	Version		display RAS code and driver version
	View		<filename> view a text file
	Wdog		
		switch	[on off] set on/off wdog
		cnt	[value] display watchdog counts value: 0-34463
	romreset		restore default romfile

	Socket			display system socket information
	Filter			
		netbios		
	roadrunner			
		debug	<level>	enable/disable roadrunner service 0: diable <default> 1: enable
		display	<iface name>	display roadrunner information iface-name: enif0, wanif0
		restart	<iface name>	restart roadrunner
	Ddns			
		debug	<level>	enable/disable ddns service
		display	<iface name>	display ddns information
		restart	<iface name>	restart ddns
		logout	<iface name>	logout ddns
	Cpu			
		display		display CPU utilization

Exit Command

[Home](#)

Command				Description
exit				exit smt menu

Ethernet Related Command

[Home](#)

Command				Description
ether				
	Config			display LAN configuration information
	Driver			
		cnt		
			disp <name>	display ether driver counters
			ioctl <ch_name>	Useless in this stage.
			status <ch_name>	see LAN status
	version			see ethernet device type
	edit			
		load	<ether no.>	load ether data from spt
		save		save ether data to spt

Wireless LAN Related Command

[Home](#)

Command				Description
wlan				
	active		[on/off]	set on/off wlan
	association			display association list
	chid		[channel id]	set channel
	diagnose			self-diagnostics
	essid		[ess id]	set ESS ID
	scan			scan wireless channels
	version			display WLAN version information

IP Related Command

[Home](#)

Command				Description
ip				
	address		[addr]	display host ip address
	alias		<iface>	alias iface
	aliasdis		<0 1>	disable alias

arp				
	status	<iface>		display ip arp status
dhcp			<iface>	
	client			
			release	release DHCP client IP
			renew	renew DHCP client IP
	status	[option]		show dhcp status
dns				
	query			
	server	<primary> [secondary] [third]		set dns server
	stats			
	default			set default DNS server
httpd				
icmp				
	status			display icmp statistic counter
	discovery	<iface> [on/off]		set icmp router discovery flag
ifconfig			[iface] [ipaddr] [broadcast <addr> mtu <value> dynamic]	configure network interface
ping			<hostid>	ping remote host
route				
	status		[if]	display routing table
	add		<dest_addr/default>[/<bits>] <gateway> [<metric>]	add route
	addiface		<dest_addr/default>[/<bits>] <gateway> [<metric>]	add an entry to the routing table to iface
	addprivate		<dest_addr/default>[/<bits>] <gateway> [<metric>]	add private route
	drop		<host addr> [/<bits>]	drop a route
status				display ip statistic counters
udp				
	status			display udp status
rip				
tcp				
	status		[tcb] [<interval>]	display TCP statistic counters
telnet			<host> [port]	execute telnet client command
tftp				
traceroute			<host> [ttl] [wait] [queries]	send probes to trace route of a remote host
xparent				
	join		<iface1> [<iface2>]	join iface2 to iface1 group
	break		<iface>	break iface to leave ipxparent group
igmp				
	debug		[level]	set igmp debug level
	forwardall		[on/off]	turn on/off igmp forward to all interfaces flag
	querier		[on/off]	turn on/off igmp stop query flag
	iface			
			<iface> group tm <timeout>	set igmp group timeout
			<iface> interval <interval>	set igmp query interval
			<iface> join <group>	join a group on iface
			<iface> leave <group>	leave a group on iface
			<iface> query	send query on iface
			<iface> rsptime [time]	set igmp response time
			<iface> start	turn on of igmp on iface
			<iface> stop	turn off of igmp on iface
			<iface> ttl <threshold>	set ttl threshold
			<iface> v1compat [on/off]	turn on/off v1compat on iface

		robustness	<num>	set igmp robustness variable
		status		dump igmp status

Bridge Related Command

[Home](#)

Command				Description
Bridge				
	cnt			related to bridge routing statistic table
		Disp		display bridge route counter
		Clear		clear bridge route counter
	stat			related to bridge packet statistic table
		Disp		display bridge route packet counter
		Clear		clear bridge route packet counter

Radius Related Command

[Home](#)

Command				Description
radius				
	auth			show current radius authentication server configuration
	acct			show current radius accounting server configuration

802.1x Related Command

[Home](#)

Command				Description
8021x				
	debug	Level	[debug level]	set ieee802.1x debug message level
		Trace		show all supplications in the supplication table
		User	[username]	show the specified user status in the supplicant table