

ZyXEL Confidential



Firmware Release Note

Prestige 650M-67
ADSL over ISDN/U-R2 Modem

Release 3.40(SN.0)c0

Date: August 24, 2004
Author: David Su

ZyXEL Prestige 650M-67 Release 3.40(SN.0) Release Note

Date: August 24, 2004

Supported Platforms:

ZyXEL Prestige 650M-67

Versions:

ZyNOS F/W Version: V3.40(SN.0) | 8/24/2004 10 :28 :09

BootBase : V1.00| 6/14/2004 21:32:17

Notes:

The Prestige 650M-67 is a high performance **ADSL/ADSL2** modem which is designed for residential user to have Internet access and LAN-to-LAN application over the existing copper line. P650M-67 takes advantage of much higher data rate than ADSL, speed up to 12Mbps (ADSL2), greater reach, faster start-up, and better power management.

P650M-67 provides one auto-detection 10/100BASE-T Ethernet port for connection to the user's local network, and a single RJ-11/RJ-45 port for connection to ADSL/ADSL2 line.

The version of Alcatel modem code is 1.1.7.252.

1. Known Issues:

1. Can't reach line rate with small packets 64/128 bytes if 2 PVCs are connected simultaneously.
2. Need to reboot system to activate remote node if user modifies the settings.

2. Features:

Modification in 3.40(SN.0)b1 | 7/2/2004

1. Create this project.

Modification in 3.40(SN.0)b2 | 7/9/2004

1. [FEATURE ENHANCED]

ZyXEL Confidential

Symptom: Support firmware upgrade utility.

2. [BUG FIXED]

Symptom: Add protection to prevent system crash when connected to company network.

3. [BUG FIXED]

Symptom: Create enough buffers to support 2 PVC connections.

Modification in 3.40(SN.0)b3 | 7/26/2004

1. [BUG FIXED]

Symptom: The restored default romfile settings by pressing reset button or issuing CI command “sys romreset” are not consistent with default romfile.

Modification in 3.40(SN.0)b4 | 8/10/2004

1. [BUG FIXED]

Symptom: Can't setup 2nd remote node if the VPI is conflict with the 1st remote node.

2. [BUG FIXED]

Symptom: The downstream halts while performing bi-directional test through AX4000 by 522/282 frame sizes.

3. [BUG FIXED]

Symptom: Poor throughput of small packets (64/128) through SmartApplication.

4. [BUG FIXED]

Symptom: The encapsulation selection of “wan node encap” should be “1483” only.

5. [FEATURE ENHANCED]

Symptom: Add commands “sys wdog sw on”, “sys quick enable”, “sys quick enable”, “wan adsl rate off” and “wan adsl errorsecond shutdown 30” in autoexec.net.

Modification in 3.40(SL.0)b5 | 8/17/2004

1. [BUG FIXED]

Symptom: The downstream traffic will stop with packet sizes 282/522 bytes if connect 2 PVCs.

CI Command List

Command Class List Table		
System Related Command	Exit Command	Ethernet Related Command
WAN Related Command	IP Related Command	Bridge Related Command
LAN Related Command		

ZyXEL Confidential

System Related Command

[Home](#)

Command			Description
sys			
	countrycode	[countrycode]	set country code
	dir		display file directory
	date	[year month date]	set/display date
	edit	<filename>	edit a text file
	feature		display feature bit
	hostname	[hostname]	display system hostname
	stdio	[second]	change terminal timeout value
	time	[hour [min [sec]]]	display/set system time
	version		display RAS code and driver version
	view	<filename>	view a text file
	wdog		
	switch	[on/off]	set on/off wdog
	cnt	[value]	display watchdog counts value: 0-34463
	dead		let watch dog take place using while loop
	romreset		restore default romfile
	password		change system password
	datetime		
	period		day period to synchronize with time server
	socket		display system socket information
	atsh		display manufactory data
	cpu		
	display		display CPU utilization

Exit Command

[Home](#)

Command			Description
exit			exit smt menu

Ethernet Related Command

[Home](#)

Command			Description
ether			
	config		display LAN configuration information
	driver		
	cnt		
		disp <name>	display ether driver counters
		clear <name>	clear ether driver counters
	status	<ch_name>	see LAN status
	config	[011=auto normal] [011=101100] [011=HD1FD] <ch-name>	configure mac phy mode
	version		see ethernet device type

ZyXEL Confidential

WAN Related Command

[Home](#)

Command			Description
wan	adsl		
		chandata	ADSL channel data, line rate
		close	close ADSL line
		linedata	
			near
			far
		open	open ADSL line
		opencmd	open ADSL line with specific standard
			gdm
			multimode
		opmode	show the operational mode
		rateadap	[on off]
		perpdata	show performance information,CRC,FEC, error seconds..
		reset	reset ADSL modem, and must reload the modem code again
		status	ADSL status (ex: up, down or wait for init)
		targetnoise	[value]
		modem_code	display modem code version.
	Hwsar	disp	display hwsar packets incoming/outgoing information
		clear	clear hwsar packets information
	Node	index	[1~2]
		clear	clear the parameters of the temporary WAN profile
		save	save the related parameters of WAN node
		display	display WAN profile configuration in buffer
		ispname	[ISP name]
		enable	enable the remote node
		disable	disable the remote node
		encap	[1483]
		mux	[vc llc]
		vpi	[num]
		vci	[num]
		qos	[ubr cbr vbr]
		pcr	[num]
		scr	[num]
		mbs	[num]
		bridge	[on off]
		routeip	[on off]

ZyXEL Confidential

IP Related Command

[Home](#)

Command			Description
ip			
	address	[addr]	display host ip address
	arp		
	status	<iface>	display ip arp status
	add	<hostid> ether <ether addr>	add arp information
	resolve	<hostid>	resolve ip-addr
	drop	<hostid> [hardware]	drop arp
	flush		flush arp table
	publish		add proxy arp
	ifconfig	[iface] [ipaddr] [broadcast <addr> lmtu <value> dynamic]	configure network interface
	ifdrop	<iface>	chaek if iface is available.
	ping	<hostid>	ping remote host
	route		
	status	[if]	display routing table
	add	<dest_addr default>[/<bits> <gateway> [<metric>]	add route
	addiface	<dest_addr default>[/<bits> <gateway> [<metric>]	add an entry to the routing table to iface
	addprivate	<dest_addr default>[/<bits> <gateway> [<metric>]	add private route
	drop	<host addr> [/<bits>]	drop a route
	flush		flush route table
	lookup	<addr>	find a route to the destination
	errcnt		
		disp	display routing statistic counters
		clear	clear routing statistic counters
	status		display ip statistic counters
	tcp		
	ceiling	[value]	TCP maximum round trip time
	floor	[value]	TCP minimum rtt
	irtt	[value]	TCP default init rtt
	kick	<tcb>	kick tcb
	limit	[value]	set tcp output window limit
	mss	[value]	TCP input MSS
	reset	<tcb>	reset tcb
	rtt	<tcb> <value>	set round trip time for tcb
	status	[tcb] [<interval>]	display TCP statistic counters
	syndata	[on off]	TCP syndata piggyback
	trace	[on off]	turn on/off trace for debugging
	window	[tcb]	TCP input window size

ZyXEL Confidential

Bridge Related Command

[Home](#)

Command			Description
bridge			
	cnt		related to bridge routing statistic table
		disp	display bridge route counter
		clear	clear bridge route counter
	stat		related to bridge packet statistic table
		disp	display bridge route packet counter
		clear	clear bridge route packet counter

LAN Related Command

[Home](#)

Command			Description
lan			
	index	<1:main LAN>	Select main LAN Interface
	ipaddr	<address> <subnet mask>	Set lan ip address.
	display		Display LAN parameters
	clear		Clear the Working Buffer
	save		Save LAN related parameters