

ZyXEL Confidential

# ZyXEL

Firmware Release Note

## P-793H

### Standard version

Release 3.40(RQ.0)C0

**Date:**  
**Author:**

**Sep 06,2006**  
**Topping Tang**

# ZyXEL P-793H Standard Version Release 3.40(RQ.0)C0 Release Note

**Date:** Sep 06, 2006

## **Supported Platforms:**

ZyXEL P-793H

## **Versions:**

ZyNOS Version : V3.40(RQ.0) | 09/06/2006 10:31:00  
Bootbase Version : V1.09 | 06/30/2006 17:27:00

## **Notes:**

## **Known Issues:**

## **Features:**

### **Modifications in V3.40(RQ.0)C0 | 09/06/2006 10:31:00**

1. Change to FCS.

### **Modifications in V3.40(RQ.0)b3 | 08/25/2006 16:00:00**

1. [BUG FIX] SPRID: 060728957  
Symptom: Some information in release note is not correct.  
Condition: 1)Menu 1 “System Name=?” in release note, but it is P-793H in SMT and GUI. 2)Menu 21 it shows 3 items in release note, but it only has two items in SMT. There is no “View Firewall Log” item in SMT.
2. [BUG FIX] SPRID: 060728958  
Symptom/ Condition: Any help page about VPN can't be found, and there is no information about dial backup in the help page of Wan Backup.
3. [BUG FIX] SPRID: 060728959  
Symptom: There is an additional page in Wan->More Connection Setup->SUA Only Edit.  
Condition: Step1 Restore default romfile. Step2 Enter GUI->Advance Setup->Wan->More Connections, Edit one connection and Enter NAT SUA Only Edit in this page, After Edit the port forwarding then apply it. It will show a Full feature Address Mapping Rule edit page, and the configuration in this page can be saved in NAT->Address Mapping Rule.
4. [BUG FIX] SPRID: 060728960  
Symptom/ Condition: There is some debug information in Procomm Plus Terminal

ZyXEL Confidential

when testing throughput. And it also shows some debug information sometimes when you configure the device.

5. [BUG FIX] SPRID: 060728961  
Symptom/ Condition: atwm can't change MAC correctly in debug mode .If you want to change MAC to 001349123456, but it will be changed to 00a0c5123456.
6. [BUG FIX] SPRID: 060731046  
Symptom/ Condition: Wizard->Internet Configuration->Bridge+RFC1483, it will show an unneeded page to ask you to enter the IP address.
7. [BUG FIX] SPRID: 060731047  
Symptom/ Condition: Configure Internet parameters in wizard setup to route mode, the NAT will be set to None.
8. [BUG FIX] SPRID: 060731050  
Symptom/ Condition: Wizard->Internet Configuration ->Route+RFC1483, it will show a page to ask you to enter IP address, when you apply it after configuration of IP address, it will show an error message "Gateway IP Address should not be 0.0.0.0!".
9. [BUG FIX] SPRID: 060731052  
Symptom/ Condition: Even configure Internet Connection to bridge mode, it will also show IP Address item in Advance Setup->Network->Wan->Internet Connection page.
10. [BUG FIX] SPRID: 060801048  
Symptom/Condition: VPN can't be disconnect in GUI->Advance Setup->Security->VPN->Monitor and it shows "HTML Item value can't be empty4932007", and this error message will also show when you use refresh button in this page.
11. [BUG FIX] SPRID: 060801050  
Symptom/ Condition: VPN rule in Manual mode can't be showed correctly if you edit again, it will show VPN set in IKE mode.
12. [BUG FIX] SPRID: 060801051  
Symptom/ Condition: Error page can't show friendly in VPN Manual mode when you enter keys incorrectly.
13. [BUG FIX] SPRID: 060807394  
Symptom/ Condition: "ip nat addrmap clear [map#] [rule#]" can't work correctly and it shows "please do rule setting first".
14. [BUG FIX] SPRID: 060807395  
Symptom: When you add Firewall Rules, another rule will be added automatically  
Condition: Step1Add rules one by one Step2.When you add the fourth rule, the rule you have edited will be added, and the fifth rule with former setting (rule 3) will be added automatically. Step3.You can add rules continually; it always shows the same results. For example, If you add the sixth rule, the seventh rule with default setting will be added automatically
15. [BUG FIX] SPRID: 060807396  
Symptom: Append firewall rules can not work when rule number larger than 9  
Condition: Step1. Add nine firewall rules. Step2. Insert a new rule after rule number 9, it shows "INTERNEL ERROR". But insert a new rule after rule number 1~8, it can be inserted successfully. Step3. When you insert a rule after rule number which larger than 9, it can't be inserted, but if you insert after rule number 1~8, it will be inserted

**ZyXEL Confidential**

successfully.

16. [BUG FIX] SPRID: 060807397

Symptom: When deleting firewall rules, it has problem.

Condition: Step1. In default setting, add 5~6 firewall rules in GUI. Step2. Delete one of the rules, two rules may be deleted together and the firewall rule numbers may be disordered. Step3. It will happen sometimes, but the frequency is very high.

17. [BUG FIX] SPRID: 060807398

Symptom/ Condition: In GUI->Security->Firewall->Rules, add rules in 4 packet directions, when we change any rule "Active" check box in one of the directions, the others' will be changed accordingly.

18. [BUG FIX] SPRID: 060807399

Symptom: Firewall rules can't be added correctly with range address of source address or destination address.

Condition: Step1 Enter GUI->Advance->Security->Firewall->Rules->Edit Rules. Step2 Select "Range Address" in Source Address or Destination Address and enter IP Range like this "192.168.100.22-192.168.100.36", add this range to the list and remove "Any" then apply this rule, it will shows error information. Step3 Edit the address range you entered to "192.168.99.22-192.168.99.36" then apply the rule, it will be saved correctly.

19. [BUG FIX] SPRID: 060807400

Symptom/ Condition: In GUI firewall rules edit page, the Source Address and Destination Address can only be set to Single, Range or Subnet. Single selection can only contain two IP Address when Range and Subnet can only contain one. Additionally, Single, Range and Subnet can't be compatible.

20. [BUG FIX] SPRID: 060807401

Symptom/ Condition: Administrator Inactive Timer can't be saved correctly. If you change the time to 1 min in GUI, enter SMT then enter GUI again, it shows 5 min in GUI, and change to SMT it also shows 5 min.

21. [BUG FIX] SPRID: 060807402

Symptom/ Condition: Log Settings->Active Log and Alert can only be save once when edit this page. When you change some setting in this section and want to apply it, it will show "INTERNAL ERROR" and the modification can't be saved.

22. [BUG FIX] SPRID: 060807403

Symptom: Bandwidth MGMT rule with bandwidth larger than 65535 can't be added correctly.

Condition: Step1.Bandwidth MGMT->Summary LAN interface->Speed set to 100000. Step2. Enter Bandwidth MGMT->Rule Setup and add a rule with Bandwidth smaller than 65536, it will be added correctly. Step3. Enter Bandwidth MGMT->Rule Setup and add a rule with Bandwidth larger than 65536, the bandwidth which will be saved is the bandwidth you have entered subtract 65536, for example you have entered 65537, it will be saved as 1.

23. [BUG FIX] SPRID: 060807404

Symptom: Device will crash when email logs or alerts.

Condition: Step1. Edit Log Settings->E-Mail Log Settings and save it. Step 2 Click Email Log now in View Log page or wait for the Log Schedule, when it tries to e-mail

**ZyXEL Confidential**

- logs, the device will crash.
24. [BUG FIX] SPRID: 060807417  
Symptom/ Condition: Wizard setup->Bandwidth Management setup will set the summary speed to 100000/800 (down/up) as default , but P-793 is based on S.HDSL and the down speed should be equal to up speed.
25. [BUG FIX] SPRID: 060808539  
Symptom/ Condition: SNMP and DNS also can work even we have changed the access status in Remote Node MGMT
26. [BUG FIX] SPRID: 060810704  
Symptom/ Condition: When we enable the Universal Plug and Play(UPnP) Service ,MSN White board can't work correctly.
27. [BUG FIX] SPRID: 060811740  
Symptom/ Condition: The number of NAT session can't reach to 2048.
28. [BUG FIX] SPRID: 060807416  
Symptom/ Condition: MBM rules can't work correctly.
29. [BUG FIX] SPRID: 060731048  
Symptom/ Condition: Advance Setup- > Status- > DSL Standard always shows "Annex A" even the DSLAM mode in Annex B and the wan line is up, it only reads the DSL mode in P-793H and the DSL standard has been set to Annex A as default in P-793H.

**Modifications in V3.40(RQ.0)b2 | 07/10/2006 17:27:00**

1. Change Default Romfile.

**Modifications in V3.40(RQ.0)b1 | 06/08/2006 16:28:08**

1. First Release.

**Annex A CI Command List**

Command Class List Table		
<a href="#">System Related Command</a>	<a href="#">Exit Command</a>	<a href="#">Ethernet Related Command</a>
<a href="#">WAN Related Command</a>	<a href="#">IP Related Command</a>	<a href="#">Bridge Related Command</a>
<a href="#">XDSL Related Command</a>		

System Related Command

[Home](#)

Command			Description
sys			
	adjtime		retrive date and time from Internet
	atsh		display MRD field
	callhist		
	display		display call history
	remove	<index>	remove entry from call history
	countrycode	[countrycode]	set country code
	date	[year month date]	set/display date
	domainname		display domain name
	edit	<filename>	edit a text file
	extraphnum		maintain extra phone numbers for outcalls
	add	<set 1-3> <1st phone num> [2nd phone num]	add extra phone numbers
	display		display extra phone numbers
	node	<num>	set all extend phone number to remote node <num>
	remove	<set 1-3>	remove extra phone numbers
	reset		reset flag and mask
	feature		display feature bit
	hostname	[hostname]	display system hostname
	log		
	clear		clear log error
	disp		display log error
	online	[on off]	turn on/off error log online display
	stdio	[second]	change terminal timeout value
	time	[hour [min [sec]]]	display/set system time
	trcdisp	parse, brief, disp	monitor packets
	syslog		
	server	[destIP]	set syslog server IP address
	facility	<FacilityNo>	set syslog facility
	type	[type]	set/display syslog type flag
	mode	[on off]	set syslog mode
	version		display RAS code and driver version
	view	<filename>	view a text file
	wdog		
	switch	[on off]	set on/off wdog
	cnt	[value]	display watchdog counts value: 0-34463
	romreset		restore default romfile
	socket		display system socket information
	ddns		
	debug	<level>	enable/disable ddns service
	display	<iface name>	display ddns information
	restart	<iface name>	restart ddns
	logout	<iface name>	logout ddns

**ZyXEL Confidential**

	cpu		
		display	display CPU utilization
	xmodemmode	[crc checksum]	select xmodem mode

Exit Command

[Home](#)

Command			Description
exit			exit smt menu

Ethernet Related Command

[Home](#)

Command			Description
ether			
	config		display LAN configuration information
	driver		
		Cnt	
		disp <name>	display ether driver counters
		Status <ch_name>	see LAN status
	config	[0 1=auto normal] [0 1=10 100] [0 1=HD FD] <ch-name>	Configure LAN Settings Auto/Normal, 100/10 Mbps, Half/Full Duplex
	version		see ethernet device type

WAN Related Command

[Home](#)

Command			Description
Wan	atm	test [fix rand period oam loopback]	Generate ATM traffic
	hwsar	Disp	Display hwsar packets incoming/outgoing information
		Clear	Clear hwsar packets information
		Sendoam	Send OAM packets: <vpi> <vci> <f5> <end-to-end> <type:0(AIS) 1(RDI) 2(LoopBack)>

IP Related Command

[Home](#)

Command			Description
ip			
	address	[addr]	display host ip address
	alias	<iface>	alias iface
	aliasdis	<0 1>	disable alias
	arp		
		status <iface>	display ip arp status
	dhcp	<iface>	
		client	
		release	release DHCP client IP
		renew	renew DHCP client IP
		status [option]	show dhcp status
	dns		
		query	
		stats	
		clear	clear dns statistics
		disp	display dns statistics
	icmp		
		status	display icmp statistic counter
		discovery <iface> [on off]	set icmp router discovery flag
	ifconfig	[iface] [ipaddr] [broadcast <addr>  mtu <value> dynamic]	configure network interface

**ZyXEL Confidential**

	ping		<hostid>	ping remote host
	route			
		status	[if]	display routing table
		add	<dest_addr/default>[/<bits> <gateway> [<metric>]	add route
		addiface	<dest_addr/default>[/<bits> <gateway> [<metric>]	add an entry to the routing table to iface
		addprivate	<dest_addr/default>[/<bits> <gateway> [<metric>]	add private route
		drop	<host addr> [/<bits>]	drop a route
	status			display ip statistic counters
	udp			
		status		display udp status
	tcp			
		status	[tcb] [<interval>]	display TCP statistic counters
	xparent			
		join	<iface1> [<iface2>]	join iface2 to iface1 group
		break	<iface>	break iface to leave ipxparent group
	igmp			
		debug	[level]	set igmp debug level
		forwardall	[on/off]	turn on/off igmp forward to all interfaces flag
		querier	[on/off]	turn on/off igmp stop query flag
		iface		
			<iface> grouptm <timeout>	set igmp group timeout
			<iface> interval <interval>	set igmp query interval
			<iface> join <group>	join a group on iface
			<iface> leave <group>	leave a group on iface
			<iface> query	send query on iface
			<iface> rsptime [time]	set igmp response time
			<iface> start	turn on of igmp on iface
			<iface> stop	turn off of igmp on iface
			<iface> ttl <threshold>	set ttl threshold
			<iface> v1compat [on/off]	turn on/off v1compat on iface
		robustness	<num>	set igmp robustness variable
		status		dump igmp status

**Bridge Related Command**

[Home](#)

Command			Description
bridge			
	cnt		related to bridge routing statistic table
		disp	display bridge route counter
		clear	clear bridge route counter
	stat		related to bridge packet statistic table
		disp	display bridge route packet counter
		clear	clear bridge route packet counter

**XDSL Related Command**

[Home](#)

Command			Description
xdsl			