

# ZyXEL VES-1124 V3.50(LP.1)

## Release Note/Manual Supplement

---

---

**Date:** Nov. 02, 2004

This document describes the features in the VES-1124 product for its 3.50(LP.1) release.

### ***Support Platforms:***

---

ZyXEL VES-1124 V3.50(LP.1) supports models: ZyXEL VES-1124

### ***Version:***

---

ZyNOS Version: V3.50(LP.1) | 11/02/2004 17:20:55

BootBase Version: V1.01(VES-1124) | 05/27/2004 17:20:55

### ***Known Issue:***

---

1. Ethernet AC101 PHY are not compatible with specific PHY.
2. Cannot generate pause frame when multiple vdsl ports send packets to uplink port.
3. Bandwidth control works only when Flow control enabled.
4. When GVRP enable, leave timer and leave all timer should be increased when lots of dynamic VLAN join.
5. Per port PVID setting is limited in set range(1-255, 256-511, ..., 3840-4094). If port 1 is set PVID in one of the set range, the other ports PVID also should be set to the same set range.
6. Keep pressing port test button before accomplish port test will cause system reboot.

### ***Bug Fix V3.50(LP.1):***

---

1. Process Port Test before VDSL link up will cause system crash.
2. Mirror function cannot work correctly when mirrored port is port 25 and port 26.

### ***Bug Fix V3.50(LP.1)b3:***

---

1. Gray out the edit box of Management VID in port based VLAN mode.
2. Gray out the edit box of VID in Static MAC Forwarding page for port based VLAN mode.
3. Remove one garbage string in port based VLAN table that is in last row and last column.
4. Fix bug that pause timer may overflow problem.
5. Add workaround when READY BIT no response.
6. Fix bug that remote PHY invalid setting may cause traffic hang lock.
7. Change LED light on to blinking when packet into device.

### ***Bug Fix V3.50(LP.1)b2:***

---

1. Port test in Diagnostic menu will fail in port based vlan mode.

### ***Bug Fix V3.50(LP.1)b1:***

---

1. Packet from CPU will flood to other ports in port based vlan.
2. VDSL CPE Ethernet link down will not flush arp table.

### **Bug Fix V3.50(LP.0):**

---


1. FTP cannot work correctly.
2. MIB display error.
3. Help Page binding problem.

### **Features:**

---

#### **1. VDSL Common Setup**

Providing mechanisms for setting VDSL system-wide parameters, including band plans of ETSI 997, ANSI 998, 10BaseS, and Power Back Off (PBO) enable/disable.



#### **2. VDSL Profile Management:**

The profile management is used for creating/modifying/deleting VDSL profiles used by each ports for different VDSL parameters. Currently we provide maximum 24 profiles for all system. One of the profiles named "DEFVAL" is the default profile of the system and can not be deleted. Any changes of the profiles will cause the VDSL port retrain.

Web Configurator - Microsoft Internet Explorer  
 檔案(F) 編輯(E) 檢視(V) 我的最愛(A) 工具(T) 說明(H)  
 地址 http://172.21.100.37/

**ZyXEL** Status

VISION VES-1124

**MENU**  
 Basic Setting  
 Advanced Application  
 Routing Protocol  
 Management  
 System Info  
 General Setup  
 Switch Setup  
 IP Setup  
 Port Setup  
 VDSL Common Setup  
 VDSL Profile Setup

**VDSL Profile Setup**

Name: DEFVAL  
 Downstream Line Rate: 12.50Mbps  
 Upstream Line Rate: 12.50Mbps  
 Rate Adaptive:  Fixed Mode  Rate Adaptive Decrease Mode


Add Cancel Clear

Name	Line Rate	Applied Ports	Delete
DEFVAL	12M/12M	1-24	<input type="checkbox"/>

Delete Cancel

### 3. VDSL Port Profile Assignment

In the Port Setup page, the user can assign which profile to be used for each port.



### ***Firmware Upgrade:***

The VES-1124 uses FTP to upgrade firmware in run-time through its built-in FTP server. You can use any FTP client (for example, [ftp.exe](#) in Windows) to upgrade VES-1124. The upgrade procedure is as follows:

#### **Upgrade VES-1124 FW:**

```
C:\> ftp <VES-1124 IP address>
User : <Enter>
Password: 1234
230 Logged in
ftp> put 350LP1C0.bin ras
ftp> bye
```

Where

- User name : just press <Enter>
- Password : the management password, 1234 by default

- 350LP1C0.bin : the name of firmware file you want to upgrade
- ras : the internal firmware name in VES-1124

### ***Configuration Upgrade:***

---

The VES-1124 uses FTP to upgrade configuration in run-time through its built-in FTP server. You can use any FTP client (for example, [ftp.exe](#) in Windows) to upgrade VES-1124. The upgrade procedure is as follows:

#### **Upgrade VLC1124A configuration:**

```
C:\> ftp <VES-1124 IP address>
User : <Enter>
Password: 1234
230 Logged in
ftp> put 350LP1C0.rom rom-0
ftp> bye
```

Where

- User name : just press <Enter>
- Password : the management password, 1234 by default
- 350LP1C0.rom : the name of configuration file you want to upgrade
- rom-0 : the internal configuration name in VES-1124

### ***Commands Table:***

---

- [Partial VDSL Profile and VDSL Port commands are not fully supported](#)

sys	snmp	GetCom	[<community> munity ]	Set or view community of GetRequest.
		SetCom	[<community> munity ]	Set or view community of SettRequest.
		TrustedH	[<hsot>]	Set or view trusted host.
		ost		
		trapCom	[<community> munity ]	Set or view community of Trap
		trapDest	[<destination> ]	Set or view trap server.
		disp		View snmp setting.
cluster	active		<name>	Active cluster
	inactive		<name>	Inactive cluster
	add		<MAC addr> <password >	Add a member into cluster
	remove		<MAC addr>	Remove a member from cluster.
	ShowMe			Show member list
	meber			
	showCan			Show candidate list

	didate									
	status									Show cluster status
config	save									Save configuration
Switch commands: The following commands are under “ <b>sys switch</b> ”										
garp	status									show garp timer status
	timer	<join	<leave	<leave all						set garp timer <join timer>
		timer(ms)	timer(ms)>	timer<ms>						<leave timer> <leave all
		>								timer>
gvrp	status									show gvrp status
	enable									enable gvrp function
	disable									disable gvrp function
qos	defpri	<port>	[<0..7>]							set the default ingress User
										Priority for this port
	map	<0..7>	[<queue>]							<port>.
										User Priority to Traffic
										Class mapping.
vlan1	port	status	<port>							show port <port> VLAN
q		defaultVI	<port>	<VID>						information.
		D								set defaultVID<VID> of
		accept	<port>	<all tagged						this port<port>.
		>		>						set acceptFrameType of
		gvrp	<port>	<enable dis						this port.
				able>						Enable/disable the gvrp
										function of this port
										<port>.
svlan	cpu	<VLAN ID>								Set VLAN ID of cpu.
	setentry	<name>	<VID>	<port>	<adctl>	<<tagctl>				set static
										entry.<VID>
										delete static entry<VID>
										active the static entry with
										<VID>
										inactive the static entry
										with <VID>
										show the static entry table.
										Show vlan1q current table.
driver	count	disp								Show the switch NDIS
										level counters(CPU
										interface)
										Clear the switch NDIS
										level counters(CPU
										interface)
rstp	bridge									<a href="#">Please reference to 802.1w</a>
		enable								Enable RSTP
		disable								Disable RSTP
		priority	<priority>							System Priority
		maxAge	<max age>							Max age timer

	helloTime	<hello time>		Hello timer
	forwardDelay	<forward delay time>		Forward delay time
	version	<STP:0 RSTP:2>		Operation Mode
port	enable	<Port_NO>		Enable this port under RSTP protocol
	disable	<Port_NO>		Disable this port under RSTP protocol
	pathCost	<Port_NO>		Cost of this path
	priority	<Port_NO>		Priority
	edgePort	<Port_NO>		If this port is an edge port
	p2pLink	<Port_NO>		Whether the Port concerned can only be connected to exactly one other Bridge or can be connected to two or more Bridges
	mcheck	<Port_NO>		802.1w chapter 17.18.10
lacp				<a href="#">Please reference to 802.3ad</a>
agg				Display aggregation information
port	enable	<Port_NO>		
	disable	<Port_NO>		
	status	<Port_NO>		
	actorAdmin			Actor means local side
	activity	[Port_NO [0:passive 1:active]]		
	display	[Port_NO]		
	key	[Port_NO [Key]]		
	priority	[Port_NO [Priority]]		
	timeout	[Port_NO [0:long_timeout 1:short_timeout]]		
	status			
	keymgmt	[on off]		
	sysPriority	<priority>		
dot1x				<a href="#">Please reference to 802.1x</a>
	enable			Enable dot1x
	disable			Disable dot1x
	status			Show dot1x global status
port	enable	<Port_NO>		Enable this port
	disable	<Port_NO>		Disable this port
	reauth	<Port_NO>	<on off>	Re-authentication

	reauthPer	<Port_NO>	<value>		Re-authentication period
	iod				
set	status	<Port_NO>			Port status
	auth	<profile   radius>			Set authentication method
	portcontrol	<port-no>	<auto  auth   unauth>		Set port authentication status
radius	server	<IP>			Server IP
	secret	<secret>			Secret key
	port	<port>			Server port
	show				Display server setting (Won't be saved in flash)
profile	add	<username>	<passwd >		Add a user profile
	delete	<idx>			Delete a user profile
	list				List profile setting
class	display				Class setting
	l2set	<src port>	<src MAC> <src vid>	<dest port>	<dest MAC> <dest vid>
	del	<class id>			Delete this class
bmstorm	disable				Broadcast Storm Control
	type	<type>			Clear current run-time settings
	basis	<type>			Broadcast/Multicast/Both
	display	[index]			Pkt/Byte
	interval	[value]			Display ports setting
	set	<port>	<dhreshold>	<direction>	Set/display monitor interval
	del	<index>			Threshold:# of pkt can be passed in the interval
					Direction:ingress/egress
					Disable on this port
mac	static				Static MAC setting
	disable				Clear current run-time settings
	display	[port]			display run-time status
	set	<port>	<MAC Addr.>	<vid>	Set static MAC of the port
	del	<port>	<MAC Addr.>	<vid>	Delete static MAC of the port
filter	disable				MAC filter setting
	display				Clear current run-time settings
	set	<src	<src MAC>	<dest	<dest MAC>
					display run-time status
					Set src/dest port/MAC

		port>	<src vid>	port>	<dest vid>	combination ( Use "*" as "don't-care" in each field)
mirror						Mirror setting
	disable					Clear current run-time settings
	display					display run-time status
	set	<src port>	<src MAC> <src vid>	<dest port>	<dest MAC> <dest vid>	Set src/dest port/MAC combination for mirror settings ( Use "*" as "don't-care" in each field)
		<input ou tput both >				
	port	<port>				What port mirror to
bw						Bandwidth Control setting
	disable					Clear current run-time settings
	display					display run-time status
	set	<src port>	<src MAC> <src vid>	<dest port>	<dest MAC> <dest vid> <Max BW>	Set src/dest port/MAC combination ( Use "*" as "don't-care" in each field)
trunk						Trunking setting
	disable					Clear current run-time settings
	display					display run-time status
	set	<group>	<# ports>			Set trunking group
	del	<group>				del trunking group
monit	Set					Set voltage, temperature
or	Status					Show Monitor status
Ip	dhcp	<Iface>	mode	<none   client>		Change DHCP mode for interface <Iface>
			status			Show DHCP status
			client	release		Release the IP address
				renew		Renew the IP address.

- **Following commands are not fully supported**

Profile commands: The following commands are under "vdsl profile "

list						List profile
create	<profile name>					Create a new profile with default setting

delete	<profile name>				Delete a profile
apply	<profile name>	<port number   all>			Apply current profile setting to other port
display	<profile name>				Display setting of current profile
set	<profile name>	name	<profile name>		Set the profile name of current profile
		uspayloadrate	max		Set the max upstream payloadrate
			min		Set the min upstream payloadrate
		dspayloadrate	max		Set the max downstream payloadrate
			min		Set the min downstream payloadrate
		rate-adaption	fix		Set rate-adaption mode to fixed mode
			adaption		Set rate-adaption mode to adaption mode
		snr	max		Set value of max snr
			min		Set value of min snr
			upstream	target	Set value of upstream target snr
			downstream	target	Set value of downstream target snr
		compatible-mode	adsl		Set to adsl compatible-mode
			pots		Set to pots compatible-mode
		usinterdelay			Set value of upstream interleave delay
		dsinterdelay			Set value of downstream interleave delay
		rfi	disable		Set rfi to disable
			standard	annex_f	Set rfi to annex f standard
				etsi	Set rfi to etsi standard
				t1e1	Set rfi to t1e1 standard
vdsl	Port	<port number   all>	enable		Set the port to line enable
			disable		Set the port to line disable
			retrain		Re-train operation for the port
			Re-provision		Re-provision for the port
			reset		Reset for the port
			remote-reset		Remote-reset CPE for the port
		<port number>	remote-test		Send EOC loopback packet for the remote test
			config	Display	Display config setting
			status	Display	Display current status for the port
			counter	Clear	Clear counter for the port
vdsl	bandplan				Set bandplan for vdsl system configuration
	Pbo	Enable			Set PBO to enable
		Disable			Set PBO to disable

### ***MIB support:***

---

The following is the private vdsl related MIB currently supported by VLC-1124A:

- accessSwitchVdslLineTable
- accessSwitchVdslVtuoPhysTable
- accessSwitchVdslVturPhysTable
- accessSwitchVdslVtuoInventoryTable
- accessSwitchVdslVturInventoryTable
- accessSwitchVdslVtuoIntervalTable
- accessSwitchVdslVturIntervalTable
- accessSwitchVdslLineConfProfileTable
- accessSwitchVturDevTable
- accessSwitchVturConfTable
- accessSwitchVturStateTable
- accessSwitchVdslVtuoPhyMCMTTable
- accessSwitchVdslVturPhyMCMTTable

### ***Test Items:***

---

1. VDSL profile create/modify/delete, and assign the profile to the specific VDSL port.
2. VDSL port retrain.
3. Load factory default.
4. IP Setting