

# **ZyXEL**

Firmware Release Note

## **ZyWALL 30W**

Release 3.61(WN.1)

**Date:**  
**Author:**

**July, 08, 2003**  
**Jason Chiang**

# ZyXEL ZyWALL 30W Standard Version Release 3.61(WN.1) Release Note

---

Date: July, 08, 2003

## Supported Platforms:

---

ZyXEL ZyWALL30W

## Versions:

---

ZyNOS Version: V3.61(WN.1) | 07/08/2003  
BootBase : V1.07 | 05/16/2003

## Notes:

---

1. The setting of ignore triangle route is on in default ROM FILE. Triangle route network topology has potential security crisis. If you are not clear about it, please refer to Appendix for the triangle route issue.
2. IKE process in phase 2 will check ID information between system and the peer. If you found that the IPSEC connection is failed, please check your settings.
3. Using Web to configure VPN, the phase 1 algorithms have been fixed to DES + MD5. If other algorithms are preferred, please use ADVANCE page to configure them.
4. When firewall turns from “off” to “on”, the firewall initialization procedure will disconnect all connections running through the ZyWALL.
5. SUA/NAT address loopback feature was enabled on ZyWALL30W by default, however, if users do not need it, a C/I command “ip nat loopback off” could turn it off.
6. In WLAN configuration, a switch for enable / disable WLAN is added. The default value is “**disable**” since WLAN without any security setting is vulnerable. Please configure MAC filter, WEP and 802.1X when you enable WLAN feature.

## Known Issues:

---

1. If Peer ID content is blank, and its ID type is IP and the secure gateway address is

0.0.0.0, the rule will be chosen when incoming packets' ID type is IP. This is because ZyWALL only check ID type when this rule's ID content is blank and ID type is IP. We will modify it in the future.

2. Sometimes on screen the "Local Area Connection" icon for UPnP disappears. The icon shows again when restarting PC.
3. The DHCP client in ZW LAN side may get an IP which is reserved by static DHCP. The situation will disappear if the client releases the IP and requests again.
4. When you use MSN messenger, sometimes you fail to open special applications, such as whiteboard, file transfer and video etc. You have to wait more than 3 minutes and retry these applications.
5. eWC->WAN IP has bugs when WAN ISP is PPPoE or PPTP. Leaving some values in remote IP or remote masks for WAN IP and then switch to dynamic IP, ZyWALL cannot dial anymore.
6. If gateway in static route belongs to WAN interface and if WAN is PPPoE/PPTP encapsulation, static route node will not add in routing table and have no function after ZyWALL reboot. So, users need to reactive static route rule to enable this function.
7. When deleting a static route rule which its IP address = 0.0.0.0 and netmask = 0.0.0.0, the routing table's default route will be deleted.
8. Click "iCard" or "Free" pages many times in few seconds, system will crash.
9. Sometimes eWC->time zone page can't be configured under IE 5.00.3315.
10. Stations using Lucent WLAN cards sometimes cannot access ZyWALL30W if Intersil 2.5/3.0 cards are inserted.
11. When going inside an empty VPN rule, pre-shared key sometimes has been filled by some values which belong to other rules automatically.
12. ZyWALL WLAN-802.1X can not connect with PC whose OS version is Windows XP SP1.

## **Restore to Factory Defaults Setting Requirement: No**

### **Features:**

---

#### **Modifications in V3.61(WN.1) | 07/07/2003**

1. Modify for formal release.
2. [FEATURE CHANGE] In default setting, change "TCP Maximum Incomplete" in eWC->Firewall->Attack Alert from 10 to 30.
3. [BUG FIX] Symptom: HTP test behavior is not correct.  
Condition: Some words get lost when doing HTP test.

#### **Modifications in V3.61(WN.1)b1 | 06/24/2003**

1. [BUG FIX] Symptom: VPN tunnel may be dropped.  
Condition: When setting phase 1 SA lifetime shorter than phase 2 SA lifetime, and PING from Responder, tunnel may fail during re-key.
2. [BUG FIX] Symptom: Tunnel will be dropped after phase 1 SA timeout.  
Condition: Set up a dynamic rule in which phase 1 SA life time is shorter than phase 2 SA life time. When the tunnel is up, after phase 1 SA timeout, the tunnel will be dropped, and the traffic will use the old IPSEC SA until it is timeout.
3. [BUG FIX] Symptom: Wireless station can't PING other machines in LAN when activate the Wireless.  
Condition: When the router is up with Wireless inactive, and then activate the WIRELESS, the station can't PING other PCs in LAN.

### **Modifications in V3.61(WN.0)b7 | 05/21/2003**

1. [BUG FIX] Symptom: Web help pages are not correct.  
Condition: Following help pages are not correct.
  - (1) eWC→LAN→IP Alias
  - (2) eWC→REMOTE MGNT→DNS
  - (3) eWC→REMOTE MGNT→FTP
  - (4) eWC→REMOTE MGNT→SNMP
  - (5) eWC→REMOTE MGNT→TELNET
  - (6) eWC→REMOTE MGNT→WWW
  - (7) eWC→SUA/NAT→Address Mapping
  - (8) eWC→FIREWALL→RULE CONFIGURATION
  - (9) eWC→FIREWALL→SOURCE ADDRESS
  - (10) eWC→FIREWALL→Custom Port
  - (11) eWC→VPN→Maunal Key
  - (12) eWC→CONTENT FILTER→Free.
  - (13) eWC→CONTENT FILTER→iCard

### **Modifications in V3.61(WN.0)b6 | 05/20/2003**

1. [BUG FIX] Symptom: Telnet console hangs when changing router's LAN IP.  
Condition: When user telnets to router from the LAN side and changes the router's LAN IP, the telnet console will hang. And user cannot telnet to router until router timeout.
2. [BUG FIX] Symptom: 802.1X is not stable.  
Condition: When router is DHCP server, it will assign IP to station periodically and the WLAN connection up and down for every 5 seconds.
3. [BUG FIX] RADIUS is not stable.  
Condition: In some RADIUS software, our router can not access the RADIUS server. Sometimes router doesn't communicate with RADIUS server.
4. [BUG FIX] Symptom: CNM doesn't work.
5. [BUG FIX] WAN will drop when using PPTP in ADSL modem.  
Condition: WAN connection will drop in case of using PPTP for ADSL modem

(Alcatel ANT1000, Alcatel SpeedTouch Home and Thomson SpeedTouch 510), especially if there is "high speed" on ADSL (512/256).

6. [BUG FIX] eWC→System→General→Administrator Inactivity Timer: When set up with some value, after reboot the value will be still 5.

### **Modifications in V3.61(WN.0)b5 | 05/09/2003**

1. [FEATURE CHANGE] Custom port is expended as 30.
2. [BUG FIX] Symptom: Sometimes "Message" field of catalog "Access Control" log is blank.  
Condition: "Message" field of catalog "Access Control" log is blank randomly whatever Firewall enables or disables.
3. [BUG FIX] Symptom: PPPoE will be triggered by port 53.
4. [BUG FIX] Symptom: Add product name in page title
5. [BUG FIX] Symptom:UPnP problem:  
Condition: When UPnP is up:
  - (1) There is no "Network gateway" in network connection.
  - (2) While MSN is up, applications can not run successfully.
6. [BUG FIX] Web help pages are not ready:
  - (1) eWC→Firewall→Rule Configuration→Source IP Address & Destination IP Address
  - (2) eWC→Firewall→Rule Configuration→Custom Port.
7. [BUG FIX] Symptom: Enable both custom DNS will cause system crash.
8. [BUG FIX] Symptom: When dial backup is up, SMT menu 4 won't change related setting when changing encapsulation.

### **Modifications in V3.61(WN.0)b4 | 05/02/2003**

1. [BUG FIX] Symptom: eWC→LOGS→Reports doesn't work.
2. [BUG FIX] Symptom: Web help pages are not correct
  - (1) Help page for eWC→WAN→WAN IP.
  - (2) Help page for eWC→LAN→LAN IP
3. [BUG FIX] Symptom: Message "Un-consistent SA Happens!!" shows on console when setting up a VPN tunnel or re-key.
4. [BUG FIX] Symptom: Telnet to machine will cause system crash when eWC→Remote management→TELNET→Secured Client IP Address is "Selected", and an IP address is inserted in the related field.
5. [BUG FIX] Symptom: After phase 2 rekey, dynamic rule cannot pass traffic anymore.  
Condition:
  - (1) Set secure gateway of a rule to 0.0.0.0, it becomes a dynamic rule and only can be responder. Trigger the tunnel by inbound request from the peer.
  - (2) After the phase 2 rekey, traffic cannot pass this tunnel anymore.
6. [BUG FIX] When "keep alive" flag turns on, disconnection in SA monitor didn't work correctly.

Condition:

- (1) Turn on keep alive flag.
- (2) Use SA monitor to disconnect the tunnel.
- (3) The tunnel will not be disconnected properly. There will be still tunnels showed on SA monitor.

**Modifications in V3.61(WN.0)b3 | 04/18/2003**

1. [ENHANCEMENT] Add new web pages:
  - (1) Add eWC→LOGS→Reports
  - (2) Add eWC→MAINTENANCE→Restart
  - (3) Add new first page.
2. [BUG FIX] Symptom: The page title should have product name, i.e., should be "ZyXEL ZyWALL 30W".
3. [BUG FIX] Symptom & Condition: If user turns on Firewall TCP reset mechanism (via CI command: "sys firewall tcprst"), log shows "Firewall sent TCP packet in response to DoS attack" when Firewall sends TCP RST to the sender. This wording is incorrect and replaces by "Access block, sent TCP RST".
4. [BUG FIX] Symptom: Web help pages are not ready.
5. [BUG FIX] Symptom: Default settings are not correct.
  - (1) eWC→WAN→Route→Dial Backup: Priority should be 15
  - (2) eWC→WIRELESS LAN→Wireless→Threshold should be 2432
6. [BUG FIX] Symptom: Sometimes Windows Messenger doesn't work through WAN to LAN.

Condition: While initiating Windows Messenger APs from WAN to LAN, router can not send and receive packets when all Messenger APs are on.
7. [BUG FIX] Symptom: When VPN is on, SA monitor shows duplicate tunnel when re-keying.
8. [BUG FIX] Symptom: In SMT 15.1.1, "Type" shows "+" when there are more than 5 characters in this column.

**Modifications in V3.61(WN.0)b2 | 03/25/2003**

1. [BUG FIX] Symptom: Wireless 802.1X doesn't work.
2. [BUG FIX] Symptom: VPN tunnel establish fail

Condition:
  - (1) Secure gateway IP address is 0.0.0.0
  - (2) Phase 1 peer ID type is IP, and peer ID content is empty or 0.0.0.0.
  - (3) Tunnel can not establish when peer dialing in.
3. [BUG FIX] Symptom: eWC→Dial Back Up doesn't exist.
4. [BUG FIX] Symptom: System crashes during tunnel establishing.

Condition: In aggressive mode, when PFS is DH 1 or DH 2, tunnel will not establish. If now watch dog is on, system will crash.

## Modifications in V3.61(WN.0)b1 | 03/07/2003

1. First release.

### Appendix 1 Remote Management Enhancement (Add SNMP & DNS Control)

#### New function

- (1) You can change the server port.
- (2) You can set the security IP address for each type of server.
- (3) You can define the rule for server access. (WAN only/LAN only, None, ALL).
- (4) The secure IP and port of the SNMP server is read only
- (5) The port of the SNMP and DNS server is read only.
- (6) The default server access of the SNMP and DNS is ALL.

#### Modification

- (1) The default value for Server access rule is ALL.
- (2) Under the default setting: You can setup the Menu 15 to forwarding the server to LAN IP address. Thus you can configure the router through the WAN and you don't need to modify the server management or filter.

Menu 24.11 - Remote Management Control		
TELNET Server:	Port = 23	Access = ALL Secured Client IP = 0.0.0.0
FTP Server:	Port = 21	Access = ALL Secured Client IP = 0.0.0.0
Web Server:	Port = 80	Access = ALL Secured Client IP = 0.0.0.0
SNMP server:	Port = 161	Access = ALL Secured Client IP = 0.0.0.0
DNS server:	Port = 53	Access = ALL Secured Client IP = 0.0.0.0

Press ENTER to Confirm or ESC to Cancel:

## Appendix 2 Trigger Port

### Introduction

Some routers try to get around this "one port per customer" limitation by using "triggered" maps. Triggered maps work by having the router watch *outgoing* data for a specific port number and protocol. When the router finds a match, it remembers the IP address of the computer that sent the matching data. When the requested data wants to come back *in* through the firewall, the router uses the port mapping rules that are linked to the trigger, and the IP address of the computer that "pulled" the trigger, to get the data back to the proper computer.


These triggered events can be timed so that they erase the port mapping as soon as they are done with the data transfer, so that the port mapping can be triggered by another Client computer. This gives the *illusion* that multiple computers can use the same port mapping at the same time, but the computers are really just taking turns using the mapping.

### How to use it

Following table is a configuration table.

Name	Incoming	Trigger
Napster	6699	6699
Quicktime 4 Client	6970-32000	554
Real Audio	6970-7170	7070
User	1001-1100	1-100

### How it works



For example, you are running a FTP Server on port 21 of machine A. And you may want this server accessible from the Internet without enabling NAT-based firewall. There are one Web Server on port 80 of machine B and another client C on the Internet.

- (1) As Prestige receives a packet from a local client A destined for the outside Internet machine B, it will check the destination port in the TCP/UDP header to see if it matches the setting in "Trigger Port" (80). If it matches, Prestige records the source IP of A (192.168.1.33) in its internal table.
- (2) Now client C (or client B) tries to access the FTP server in machine A. When Prestige to forward any un-requested traffic generated from Internet, it will first check the rules in port forwarding set. When no matches are found, it will then check the

"Incoming Port". If it matches, Prestige will forward the packet to the recorded IP address in the internal table for this port. (This behavior is the same as we did for port forwarding.)

- (3) The recorded IP in the internal table will be cleared if machine A disconnect from the sessions that matches the "Trigger Port".

#### Notes

- (1) Trigger events can't happen on data coming from *outside* the firewall because the NAT router's sharing function doesn't work in that direction.
- (2) Only one computer can use a port or port range at a time on a given real (ISP assigned) IP address.

### Appendix 3 Hard-coded packet filter for "NetBIOS over TCP/IP" (NBT)

The new set C/I commands is under "sys filter netbios" sub-command. Default values of any direction are "Forward", and trigger dial is "Disabled".

There are two CI commands:

(1) "sys filter netbios disp": It will display the current filter mode.

Example output:

```
===== NetBIOS Filter Status =====  
LAN to WAN:          Block  
WAN to LAN:          Forward  
IPSec Packets:       Forward  
Trigger Dial:        Disabled
```

(2) "sys filter netbios config <type> {on|off}": To configure the filter mode for each type. Current filter types and their description are:

Type	Description	Default mode
0	LAN to WAN	Forward
1	WAN to LAN	Forward
6	IPSec pass through	Forward
7	Trigger dial	Disabled

Example commands:

```
sys filter netbios config 0 on => block LAN to WAN NBT packets  
sys filter netbios config 1 on => block WAN to LAN NBT packets  
sys filter netbios config 6 on => block IPSec NBT packets  
sys filter netbios config 7 off => disable trigger dial
```

## Appendix 4 Traffic Redirect/Static Route Application Note

Why traffic redirect/static route be blocked by ZyWALL

ZyWALL is the ideal secure gateway for all data passing between the Internet and the LAN. For some reasons (load balance or backup line), users want traffics be re-routed to another Internet access devices while still be protected by ZyWALL. The network topology is the most important issue. Here is the common example that people misemploy the LAN traffic redirect and static route.




Figure 5-1 Triangle Route

Figure 5-1 indicates the triangle route topology. It works fine with turn off firewall. Let's take a look into the perspective toward this situation.

- Step 1. PC sends outgoing traffics through ZyWALL because default gateway assigned to it.
- Step 2. Then, ZyWALL will redirect the traffics to another gateway (ISDN/Router) as we expect.
- Step 3. But the return traffics do not go through ZyWALL because the gateway (say, P201) and the PC are on the same IP network. Any traffic will easily inject into the protected network area through the unprotected gateway.
- Step 4. When firewall turns on, it could be worse. ZyWALL will check the outgoing traffics by ACL and create dynamic sessions to allow legal return traffics. For Anti-DoS reason, ZyWALL will send RST packets to the PC and the peer because it never received TCP SYN/ACK packet.

That causes all of outgoing TCP traffics being reset!

How traffic redirect/static route works under protection - Solutions

(1) Gateway on alias IP network

IP alias allows you to partition a physical network into different logical IP networks over the same Ethernet interface. The ZyWALL supports three logical LAN interfaces via its single physical Ethernet interface with the ZyWALL itself as the gateway for each LAN network. Division of protected LAN and the other gateway into different subnets will trigger the incoming traffic back to ZyWALL and it can work as

normal function.




Figure 5-2 Gateway on alias IP network

(2) Gateway on WAN side

A working topology is suggested as below.





Figure 5-3 Gateway on WAN side

## Appendix 5 IPSec FQDN support



If ZyWALL A wants to build a VPN tunnel with ZyWALL B by passing through Router C with NAT, A can not see B. It has to secure gateway as C. However, ZyWALL B will send it packet with its own IP and its ID to ZyWALL A. The IP will be NATed by Router C, but the ID will remain as ZyWALL B sent.

In FQDN design, all three types, IP, DNS, E-Mail, can set ID content. For ID type is DNS or E-mail, the behavior is simple. ZyWALL A and ZyWALL B only checks the ID contents are consistent and they can connect.

Basically the story is the same when ID type is IP. If user configures ID content, then ZyWALL will use it as a check. So the ID content also has to match each other. For example, ID type and ID content of incoming packets must match “Peer ID Type” and “Peer ID content”. Or ZyWALL will reject the connection.

However, user can leave “ID content” blank if the ID type is IP. ZyWALL will put proper value in it during IKE negotiation. This appendix describes all combinations and behaviors of ZyWALL.

We can put all combinations in to these two tables:

(Local ID Type is IP):

Configuration		**Run-time status	
My IP Addr	Local ID Content	My IP Addr	Local ID Content
0.0.0.0	*blank	My WAN IP	My WAN IP
0.0.0.0	a.b.c.d (it can be 0.0.0.0)	My WAN IP	a.b.c.d ( 0.0.0.0, if user specified it)
a.b.c.d (not 0.0.0.0)	*blank	a.b.c.d	a.b.c.d
a.b.c.d (not 0.0.0.0)	e.f.g.h (or 0.0.0.0)	a.b.c.d	e.f.g.h (or 0.0.0.0)

\*Blank: User can leave this field as empty, doesn't put anything here.

\*\*Runtime status: During IKE negotiation, ZyWALL will use “My IP Addr” field as source IP of IKE packets, and put “Local ID Content” in the ID payload.

(Peer ID Type is IP):

Configuration		*Run-time check
Secure Gateway Addr	Peer ID Content	
0.0.0.0	blank	Just check ID types of incoming packet and machine's peer ID type. If the peer's ID is IP, then we accept it.
0.0.0.0	a.b.c.d	System checks both type and content

a.b.c.d	blank	1. System will check the ID type and the content. 2. The contents will match only if the ID content of coming packet is a.b.c.d because system will put Secure Gateway Address as Peer ID content.
a.b.c.d	e.f.g.h	1. System will check the ID type and the content. 2. The contents will match only if the ID content of coming packet is e.f.g.h.

\*Runtime Check: During IKE negotiation, we will check ID of incoming packet and see if it matches our setting of “Peer ID Type” and “Peer ID Content”.

#### Summary:

1. When Local ID Content is blank which means user doesn't type anything here, during IKE negotiation, my ID content will be “My IP Addr” (if it's not 0.0.0.0) or local's WAN IP.
2. When “Peer ID Content” is not blank, ID of incoming packet has to match our setting. Or the connection request will be rejected.

When “Secure Gateway IP Addr” is 0.0.0.0 and “Peer ID Content” is blank, system can only check ID type. This is a kind of “dynamic rule” which means it accepts incoming request from any IP, and these requests' ID type is IP. So if user put a such kind of rule in top of rule list, it may be matched first. To avoid this problem, we will enhance it in the future.

## Annex A CI Command List

Last Updated: 2003/02/17

Command Class List Table		
<a href="#">System Related Command</a>	<a href="#">Exit Command</a>	<a href="#">Device Related Command</a>
<a href="#">Ethernet Related Command</a>	<a href="#">POE Related Command</a>	<a href="#">PPTP Related Command</a>
<a href="#">Configuration Related Command</a>	<a href="#">IP Related Command</a>	<a href="#">IPSec Related Command</a>
<a href="#">Firewall Related Command</a>	<a href="#">Wireless LAN Related Command</a>	<a href="#">Bridge Related Command</a>

### System Related Command

[Home](#)

Command			Description
sys			
	adjtime		retrive date and time from Internet
	callhist		
		display	display call history
		remove	<index> remove entry from call history
	countrycode		[countrycode] set country code
	date		[year month date] set/display date
	domainname		display domain name
	edit		<filename> edit a text file
	extraphnum		maintain extra phone numbers for outcalls
		add	<set 1-3> <1 <sup>st</sup> phone num> [2 <sup>nd</sup> phone num] add extra phone numbers
		display	display extra phone numbers
		node	<num> set all extend phone number to remote node <num>
		remove	<set 1-3> remove extra phone numbers
		reset	reset flag and mask
	feature		display feature bit
	hostname		[hostname] display system hostname
	logs		
		category	
		access [0:none/1:log/2:alert/3:both]	record the access control logs
		attack [0:none/1:log/2:alert/3:both]	record and alert the firewall attack logs
		display	display the category setting
		error [0:none/1:log/2:alert/3:both]	record and alert the system error logs
		ipsec [0:none/1:log/2:alert/3:both]	record the access control logs
		ike [0:none/1:log/2:alert/3:both]	record the access control logs
		javablocked [0:none/1:log]	record the java etc. blocked logs
		mten [0:none/1:log]	record the system maintenance logs
		upnp [0:none/1:log]	record upnp logs
		urlblocked [0:none/1:log/2:alert/3:both]	record and alert the web blocked logs
		urlforward [0:none/1:log]	record web forward logs
		clear	clear log
		display	[access attack error ipsec ike javablocked mten urlblocked urlforward] display all logs or specify category logs
		errlog	
		clear	display log error
		disp	clear log error

		online	turn on/off error log online display
	load		load the log setting buffer
	mail		
		alertAddr [mail address]	send alerts to this mail address
		display	display mail setting
		logAddr [mail address]	send logs to this mail address
		schedule display	display mail schedule
		schedule hour [0-23]	hour time to send the logs
		schedule minute [0-59]	minute time to send the logs
		schedule policy [0:full/1:hourly/2:daily/3:weekly/4:none]	mail schedule policy
		schedule week [0:sun/1:mon/2:tue/3:wed/4:thu/5:fri/6:sat]	weekly time to send the logs
		server [domainName/IP]	mail server to send the logs
		subject [mail subject]	mail subject
	save		save the log setting buffer
	syslog		
		active [0:no/1:yes]	active to enable unix syslog
		display	display syslog setting
		facility [Local ID(1-7)]	log the messages to different files
		server [domainName/IP]	syslog server to send the logs
	updateSvrIP	<minute>	If there is one parameter <minute>, it will change the dns timer task timeout value. Otherwise, do dns resolve to find email log server and syslog server IP.
	pwderrtm	[minute]	Set or display the password error blocking timeout value.
	rn		
	load	<entry no.>	load remote node information
	disp	<entry no.>(0:working buffer)	display remote node information
	nat	<none sua full feature>	config remote node nat
	nailup	<no yes>	config remote node nailup
	mtu	<value>	set remote node mtu
	save	[entry no.]	save remote node information
	smt		not support in this product
	stdio	[minute]	change terminal timeout value
	time	[hour [min [sec]]]	display/set system time
	trcdisp		monitor packets
	trclog		
	trcpacket		
	syslog		
	server	[destIP]	set syslog server IP address
	facility	<FacilityNo>	set syslog facility
	type	[type]	set/display syslog type flag
	mode	[on/off]	set syslog mode
	version		display RAS code and driver version
	view	<filename>	view a text file
	wdog		
	switch	[on/off]	set on/off wdog
	cnt	[value]	display watchdog counts value: 0-34463
	romreset		restore default romfile
	server		

	access	<telnet ftp web icmp snmp dns> <value>	set server access type
	load		load server information
	disp		display server information
	port	<telnet ftp web snmp> <port>	set server port
	save		save server information
	secureip	<telnet ftp web icmp snmp dns> <ip>	set server secure ip addr
fwnotify			
	load		load fwnotify entry from spt
	save		save fwnotify entry to spt
	url	<url>	set fwnotify url
	days	<days>	set fwnotify days
	active	<flag>	turn on/off fwnotify flag
	disp		display firmware notify information
	check		check firmware notify event
	debug	<flag>	turn on/off firmware notify debug flag
cmgr			
	trace		
		disp <ch-name>	show the connection trace of this channel
		clear <ch-name>	clear the connection trace of this channel
	cnt	<ch-name>	show channel connection related counter
socket			display system socket information
filter			
	netbios		
roadrunner			
	debug	<level>	enable/disable roadrunner service 0: diable <default> 1: enable
	display	<iface name>	display roadrunner information iface-name: enif0, wanif0
	restart	<iface name>	restart roadrunner
ddns			
	debug	<level>	enable/disable ddns service
	display	<iface name>	display ddns information
	restart	<iface name>	restart ddns
	logout	<iface name>	logout ddns
cpu			
	display		display CPU utilization
filter			
	netbios		
upnp			
	active	[0:no/1:yes]	Activate or deactivate the saved upnp settings
	config	[0:deny/1:permit]	Allow users to make configuration changes. through UPnP
	display		display upnp information
	firewall	[0:deny/1:pass]	Allow UPnP to pass through Firewall.
	load		save upnp information
	save		save upnp information

## Exit Command

[Home](#)

Command			Description
exit			exit smt menu

## Device Related Command

[Home](#)

Command			Description
---------	--	--	-------------

dev				
	channel			
		drop	<channel name>	drop channel
	dial		<node#>	dial to remote node

#### Ethernet Related Command

[Home](#)

Command				Description
ether				
	config			display LAN configuration information
	driver			
		cnt		
			disp <name>	display ether driver counters
		ioctl	<ch name>	Useless in this stage.
		status	<ch name>	see LAN status
	version			see ethernet device type
	pkttest			
		disp		
			packet <level>	set ether test packet display level
			event <ch> [on/off]	turn on/off ether test event display
		sap	[ch name]	send sap packet
		arp	<ch name> <ip-addr>	send arp packet to ip-addr
	debug			
		disp	<ch name>	display ethernet debug information
		level	<ch_name> <level>	set the ethernet debug level level 0: disable debug log level 1:enable debug log (default)
	edit			
		load	<ether no.>	load ether data from spt
		mtu	<value>	set ether data mtu
		accessblock	<0:disable 1:enable>	block internet access
		save		save ether data to spt

#### POE Related Command

[Home](#)

Command				Description
poe				
	status		[ch name]	see poe status
	dial		<node>	dial a remote node
	drop		<node>	drop a pppoe call
	ether		[rfc 3com]	set /display pppoe ether type

#### PPTP Related Command

[Home](#)

Command				Description
pptp				
	dial		<rn-name>	dial a remote node
	drop		<rn-name>	drop a remote node call
	tunnel		<tunnel id>	display pptp tunnel information

#### Configuration Related Command

[Home](#)

Command				Description
config				The parameters of config are listed below.
edit	firewall	active <yes/no>		Activate or deactivate the saved firewall settings

retrieve	firewall			Retrieve current saved firewall settings
save	firewall			Save the current firewall settings
display	firewall			Displays all the firewall settings
		set <set#>		Display current entries of a set configuration; including timeout values, name, default-permit, and number of rules in the set.
		set <set#>	rule <rule#>	Display current entries of a rule in a set.
		attack		Display all the attack alert settings in PNC
		e-mail		Display all the e-mail settings in PNC
		?		Display all the available sub commands
		e-mail	mail-server <mail server IP>	Edit the mail server IP to send the alert
			return-addr <e-mail address>	Edit the mail address for returning an email alert
			e-mail-to <e-mail address>	Edit the mail address to send the alert
			policy <full   hourly  daily   weekly>	Edit email schedule when log is full or per hour, day, week.
			day <sunday   monday   tuesday   wednesday   thursday   friday   saturday>	Edit the day to send the log when the email policy is set to Weekly
			hour <0~23>	Edit the hour to send the log when the email policy is set to daily or weekly
			minute <0~59>	Edit the minute to send to log when the email policy is set to daily or weekly
			Subject <mail subject>	Edit the email subject
		attack	send-alert <yes no>	Activate or deactivate the firewall DoS attacks notification emails
			block <yes no>	Yes: Block the traffic when exceeds the tcp-max-incomplete threshold
				No: Delete the oldest half-open session when exceeds the tcp-max-incomplete threshold
			block-minute <0~255>	Only valid when sets 'Block' to yes. The unit is minute
			minute-high <0~255>	The threshold to start to delete the old half-opened sessions to minute-low
			minute-low <0~255>	The threshold to stop deleting the old half-opened session
			max-incomplete- high <0~255>	The threshold to start to delete the old half-opened sessions to max-incomplete-low
			max-incomplete- low <0~255>	The threshold to stop deleting the half-opened session
			tcp-max-incompl ete <0~255>	The threshold to start executing the block field
		set <set#>	name <desired name>	Edit the name for a set
			default-permit <forward block>	Edit whether a packet is dropped or allowed when it does not match the default set
			icmp-timeout <seconds>	Edit the timeout for an idle ICMP session before it is terminated
			udp-idle-timeout	Edit the timeout for an idle UDP session before

			<seconds>		it is terminated
			connection-timeout <seconds>		Edit the wait time for the SYN TCP sessions before it is terminated
			fin-wait-timeout <seconds>		Edit the wait time for FIN in concluding a TCP session before it is terminated
			tcp-idle-timeout <seconds>		Edit the timeout for an idle TCP session before it is terminated
			pnc <yes/no>		PNC is allowed when 'yes' is set even there is a rule to block PNC
			log <yes/no>		Switch on/off sending the log for matching the default permit
			rule <rule#>	permit <forward block>	Edit whether a packet is dropped or allowed when it matches this rule
				active <yes/no>	Edit whether a rule is enabled or not
				protocol <0~255>	Edit the protocol number for a rule. 1=ICMP, 6=TCP, 17=UDP...
				log <none match not-match both>	Sending a log for a rule when the packet none matches not match both the rule
				alert <yes/no>	Activate or deactivate the notification when a DoS attack occurs or there is a violation of any alert settings. In case of such instances, the function will send an email to the SMTP destination address and log an alert.
				srcaddr-single <ip address>	Select and edit a source address of a packet which complies to this rule
				srcaddr-subnet <ip address> <subnet mask>	Select and edit a source address and subnet mask if a packet which complies to this rule.
				srcaddr-range <start ip address> <end ip address>	Select and edit a source address range of a packet which complies to this rule.
				destaddr-single <ip address>	Select and edit a destination address of a packet which complies to this rule
				destaddr-subnet <ip address> <subnet mask>	Select and edit a destination address and subnet mask if a packet which complies to this rule.
				destaddr-range <start ip address> <end ip address>	Select and edit a destination address range of a packet which complies to this rule.
				tcp destport-single <port#>	Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, the user may repeat this command line to enter the multiple port numbers.
				tcp destport-range <start port#> <end port#>	Select and edit a destination port range of a packet which comply to this rule.
				udp destport-single <port#>	Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, users may repeat this command line to enter the multiple port numbers.
				udp destport-range <start port#> <end port#>	Select and edit a destination port range of a packet which comply to this rule.
				desport-custom <desired custom port name>	Type in the desired custom port name
delete	firewall	e-mail			Remove all email alert settings
		attack			Reset all alert settings to defaults
		set <set#>			Remove a specified set from the firewall configuration
		set <set#>	rule <rule#>		Remove a specified rule in a set from the

				firewall configuration
insert	firewall	e-mail		Insert email alert settings
		attack		Insert attack alert settings
		set <set#>		Insert a specified rule set to the firewall configuration
		set <set#>	rule <rule#>	Insert a specified rule in a set to the firewall configuration
cli				Display the choices of command list.
debug	<1 0>			Turn on/off trace for firewall debug information.

IP Related Command

[Home](#)

Command				Description
ip				
	address		[addr]	display host ip address
	alias		<iface>	alias iface
	aliasdis		<0 1>	disable alias
	arp			
		status	<iface>	display ip arp status
	dhcp		<iface>	
		client		
			release	release DHCP client IP
			renew	renew DHCP client IP
		status	[option]	show dhcp status
	dns			
		query		
		server	<primary> [secondary] [third]	set dns server
		stats		
			clear	clear dns statistics
			disp	display dns statistics
	httpd			
		debug	[on/off]	set http debug flag
	icmp			
		status		display icmp statistic counter
		discovery	<iface> [on/off]	set icmp router discovery flag
	ifconfig		[iface] [ipaddr] [broadcast <addr> [mtu <value> dynamic]	configure network interface
	ping		<hostid>	ping remote host
	route			
		status	[if]	display routing table
		add	<dest_addr default>[/<bits>] <gateway> [<metric>]	add route
		addiface	<dest_addr default>[/<bits>] <gateway> [<metric>]	add an entry to the routing table to iface
		addprivate	<dest_addr default>[/<bits>] <gateway> [<metric>]	add private route
		drop	<host addr> [/<bits>]	drop a route
	smtp			
	status			display ip statistic counters
	stroute			
		display	[rule #   buf]	display rule index or detail message in rule.
		load	<rule #>	load static route rule in buffer
		save		save rule from buffer to spt.
		config		
			name <site name>	set name for static route.

		destination <dest addr>[/<bits>] <gateway> [<metric>]	set static route destination address and gateway.
		mask <IP subnet mask>	set static route subnet mask.
		gateway <IP address>	set static route gateway address.
		metric <metric #>	set static route metric number.
		private <yes no>	set private mode.
		active <yes no>	set static route rule enable or disable.
	traceroute	<host> [ttl] [wait] [queries]	send probes to trace route of a remote host
	xparent		
	join	<iface1> [<iface2>]	join iface2 to iface1 group
	break	<iface>	break iface to leave ipxparent group
	ave		anti-virus enforce
	urlfilter		
	reginfo		
		display	display urlfilter registration information
		name	set urlfilter registration name
		eMail <size>	set urlfilter registration email addr
		country <size>	set urlfilter registration country
		clearAll	clear urlfilter register information
	category		
		display	display urlfilter category
		webFeature [block/nonblock] [activex/java/cookei/webproxy]	block or unblock webfeature
		logAndBlock [log/logAndBlock]	set log only or log and block
		blockCategory [block/nonblock] [all/type(1-14)]	block or unblock type
		timeOfDay [always/hh:mm] [hh:mm]	set block time
		clearAll	clear all category information
	listUpdate		
		display	display listupdate status
		actionFlags [yes/no]	set listupdate or not
		scheduleFlag [pending]	set schedule flag
		dayFlag [pending]	set day flag
		time [pending]	set time
		clearAll	clear all listupdate information
	exemptZone		
		display	display exemptzone information
		actionFlags [type(1-3)][enable/disable]	set action flags
		add [ip1] [ip2]	add exempt range
		delete [ip1] [ip2]	delete exempt range
		clearAll	clear exemptzone information
	customize		
		display	display customize action flags
		actionFlags [filterList/disableAllExceptTrusted/ unblockRWFToTrusted/keywordBlock/fullPath/caseInsensitive/fileName] [enable/disable]	set action flags
		logFlags [type(1-3)][enable/disable]	set log flags
		add [string] [trust/untrust/keyword]	add url string
		delete [string] [trust/untrust/keyword]	delete url string
		clearAll	clear all information
	logDisplay		display cyber log

		ftplist		update cyber list data
		listServerIP	<ipaddr>	set list server ip
		listServerName	<name>	set list server name
	treidir			
		failcount	<count>	set treidir failcount
		partner	<ipaddr>	set treidir partner
		target	<ipaddr>	set treidir target
		timeout	<timeout>	set treidir timeout
		checktime	<period>	set treidir checktime
		active	<on off>	set treidir active
		save		save treidir information
		disp		display treidir information
		debug	<value>	set treidir debug value
	nat			
		server		
			disp	display nat server table
			load <set id>	load nat server information from ROM
			save	save nat server information to ROM
			clear <set id>	clear nat server information
			edit active <yes no>	set nat server edit active flag
			edit svrport <start port> [end port]	set nat server server port
			edit intport <start port> [end port]	set nat server forward port
			edit remotehost <start ip> [end ip]	set nat server remote host ip
			edit leasetime [time]	set nat server lease time
			edit rulename [name]	set nat server rule name
			edit forwardip [ip]	set nat server server ip
			edit protocol [protocol id]	set nat server protocol
			edit clear	clear one rule in the set
		service		
			irc [on off]	turn on/off irc flag
		resetport		reset all nat server table entries
		incikeport	[on off]	turn on/off increase ike port flag
	igmp			
		debug	[level]	set igmp debug level
		forwardall	[on off]	turn on/off igmp forward to all interfaces flag
		querier	[on off]	turn on/off igmp stop query flag
		iface		
			<iface> grouptm <timeout>	set igmp group timeout
			<iface> interval <interval>	set igmp query interval
			<iface> join <group>	join a group on iface
			<iface> leave <group>	leave a group on iface
			<iface> query	send query on iface
			<iface> rsptime [time]	set igmp response time
			<iface> start	turn on of igmp on iface
			<iface> stop	turn off of igmp on iface
			<iface> ttl <threshold>	set ttl threshold
			<iface> v1compat [on off]	turn on/off v1compat on iface
		robustness	<num>	set igmp robustness variable
		status		dump igmp status
	pr			

IPSec Related Command

[Home](#)

Command		Description
ipsec		

	debug	<1 0>		turn on/off trace for IPsec debug information
	ipsec_log_disp			show IPsec log, same as menu 27.3
	route	lan	<on off>	After a packet is IPsec processed and will be sent to LAN side, this switch is to control if this packet can be applied IPsec again.
				Remark: Command available since 3.50(WA.3)
		wan	<on off>	After a packet is IPsec processed and will be sent to WAN side, this switch is to control if this packet can be applied IPsec again.
				Remark: Command available since 3.50(WA.3)
	show_runtime	sa		display runtime phase 1 and phase 2 SA information
		spd		When a dynamic rule accepts a request and a tunnel is established, a runtime SPD is created according to peer local IP address. This command is to show these runtime SPD.
	switch	<on off>		As long as there exists one active IPsec rule, all packets will run into IPsec process to check SPD. This switch is to control if a packet should do this. If it is turned on, even there exists active IPsec rules, packets will not run IPsec process.
	timer	chk_my_ip	<1~3600>	- Adjust timer to check if WAN IP in menu is changed
				- Interval is in seconds
				- Default is 10 seconds
				- 0 is not a valid value
		chk_conn.	<0~255>	- Adjust auto-timer to check if any IPsec connection has no traffic for certain period. If yes, system will disconnect it.
				- Interval is in minutes
				- Default is 2 minutes
				- 0 means never timeout
		update_peer	<0~255>	- Adjust auto-timer to update IPsec rules which use domain name as the secure gateway IP.
				- Interval is in minutes
				- Default is 30 minutes
				- 0 means never update
				Remark: Command available since 3.50(WA.3)
	updatePeerIp			Force system to update IPsec rules which use domain name as the secure gateway IP right away.
				Remark: Command available since 3.50(WA.3)
	dial	<rule #>		Initiate IPsec rule <#> from ZyWALL box
				Remark: Command available since 3.50(WA.3)
	display	<rule #>		Display IPsec rule #
	remote	key	<string>	I add a secured remote access tunnel with pre-shared key. It is a dynamic rule with local: the route's WAN IP. The algorithms with it are fixed to phase1: DES+MD5, DH1 and SA lifetime 28800 seconds; phase2: DES+MD5, PFS off, no anti-replay and SA lifetime 28800 seconds. The length of pre-shared key is between 8 to 31 ASCII characters.
		switch	<on off>	Activate or de-activate the secured remote access tunnel.

	keep_alive	<rule #>	<on off>	Set ipsec keep_alive flag
	load	<rule #>		Load ipsec rule
	save			Save ipsec rules
	config	netbios	active <on off>	Set netbios active flag
			group <group index1, group index2...>	Set netbios group
		name	<string>	Set rule name
		name	<string>	Set rule name
		keyAlive	<Yes  No>	Set keep alive or not
		natTraversal	<Yes  No>	Enable NAT traversal or not.
		lcIdType	<0:IP   1:DNS   2:Email>	Set local ID type
		lcIdContent	<string>	Set local ID content
		myIpAddr	<IP address>	Set my IP address
		peerIdType	<0:IP   1:DNS   2:Email>	Set peer ID type
		peerIdContent	<string>	Set peer ID content
		secureGwAddr	<IP address   Domain name>	Set secure gateway address or domain name
		protocol	<1:ICMP   6:TCP   17:UDP>	Set protocol
		lcAddrType	<0:single   1:range   2:subnet>	Set local address type
		lcAddrStart	<IP>	Set local start address
		lcAddrEndMask	<IP>	Set local end address or mask
		lcPortStart	<port>	Set local start port
		lcPortEnd	<port>	Set local end port
		rmAddrType	<0:single   1:range   2:subnet>	Set remote address type
		rmAddrStart	<IP>	Set remote start address
		rmAddrEndMask	<IP>	Set remote end address or mask
		rmPortStart	<port>	Set remote start port
		rmPortEnd	<port>	Set remote end port
		antiReplay	<Yes   No>	Set antireplay or not
		keyManage	<0:IKE   1:Manual>	Set key manage
		ike	negotiationMode <0:Main   1:Aggressive>	Set negotiation mode in phase 1 in IKE
			authMethod <0:PreSharedKey   1:RSASignature>	Set authentication method in phase 1 in IKE
			preShareKey <string>	Set pre shared key in phase 1 in IKE
			certFile <FILE>	Set certificate file if using RSA signature as authentication method.
			p1EncryAlgo <0:DES   1:3DES>	Set encryption algorithm in phase 1 in IKE
			p1AuthAlgo <0:MD5   1:SHA1>	Set authentication algorithm in phase 1 in IKE
			p1SaLifeTime <seconds>	Set sa life time in phase 1 in IKE
			p1KeyGroup <0:DH1   1:DH2>	Set key group in phase 1 in IKE
			activeProtocol <0:AH   1:ESP>	Set active protocol in phase 2 in IKE
			p2EncryAlgo <0:Null   1:DES   2:3DES>	Set encryption algorithm in phase 2 in IKE
			p2AuthAlgo <0:MD5   1:SHA1>	Set authentication algorithm in phase 2 in IKE
			p2SaLifeTime <seconds>	Set sa life time in phase 2 in IKE
		manual	activeProtocol <0:AH   1:ESP>	Set active protocol in manual
		manual ah	encap <0:Tunnel   1:Transport>	Set encapsulation in ah in manual
			spi <decimal>	Set spi in ah in manual
			authAlgo <0:MD5   1:SHA1>	Set authentication algorithm in ah in manual
			authKey <string>	Set authentication key in ah in manual
		manual esp	encap <0:Tunnel   1:Transport>	Set encapsulation in esp in manual
			spi <decimal>	Set spi in esp in manual
			encryAlgo <0:Null   1:DES   2:3DES>	Set encryption algorithm in esp in manual

			encryKey <string>	Set encryption key in esp in manual
			authAlgo <0:MD5   1:SHA1>	Set authentication algorithm in esp in manual
			authKey < string>	Set authentication key in esp in manual
	swSkipOverlap		<on off>	<ul style="list-style-type: none"> <li>- When a VPN rule with remote range overlaps with local range, the switch decides if a local to local packet should apply this rule.</li> <li>- Default value is “off” which means “no skip”.</li> </ul>
	adjTcpMss		<off auto user defined value>	<ul style="list-style-type: none"> <li>- After a tunnel is established, system will automatically adjust TCP MSS.</li> <li>- After all tunnels are drops, the MSS will adjust to the original value.</li> <li>- The default value is auto.</li> </ul>

#### Firewall Related Command

[Home](#)

Command		Description	
sys	Firewall		
		acl	
			disp
			Display specific ACL set # rule #, or all ACLs.
		active	<yes no>
			Active firewall or deactivate firewall
		clear	
			Clear firewall log
		cnt	
			disp
			Display firewall log type and count.
			clear
			Clear firewall log count.
		disp	
			Display firewall log
		online	
			Set firewall log online.
		pktdump	
			Dump the 64 bytes of dropped packet by firewall
		update	
			Update firewall
		dynamicrule	
		tcprst	
			rst
			Set TCP reset sending on/off.
			rst113
			Set TCP reset sending for port 113 on/off.
			display
			Display TCP reset sending setting.
		icmp	
		dos	
			smtp
			Set SMTP DoS defender on/off
			display
			Display SMTP DoS defender setting.
			ignore
			Set if firewall ignore DoS in lan/wan/dmz/wlan
		ignore	
			dos
			Set if firewall ignore DoS in lan/wan/dmz/wlan
			triangle
			Set if firewall ignore triangle route in lan/wan/dmz/wlan

## Wireless LAN Related Command

[Home](#)

Command			Description
wlan	active		Display the current active status of WLAN, 0:inactive, 1:active
		0	Deactive WALN
		1	Active WLAN
	ssid	<ssid>	Give the ESSID of WALN. The default value is “Wireless”.
	chid	<channel id>	Give the channel id. The default value is 1.
	version		Display the primary/secondary version number of the WLAN card and the version number of tertiary firmware.
	reset		Reset WLAN
	association		Display those WLAN stations associate to this device.
	tx		Only for EMI test
	rx		Only for EMI test
	basicrate		Display the current basic rate. The default value is 0x03
		<basic rate>	Set the basic rate. bit 0: 1M bps, bit 1: 2M bps, bit 2: 5.5M bps, bit 3: 11M bps
	txrate	<	Display the current data rate. The default value is 0x0f
		<tx rate>	Set the data rate. bit 0: 1M bps, bit 1: 2M bps, bit 2: 5.5M bps, bit 3: 11M bps.
	authen	<bit mask>	Set the authentication algorithm to use for authenticating the station. Bit 0: Open System. Bit 1: Shared Key.

## Bridge Related Command

[Home](#)

Command			Description
bridge			
	cnt		related to bridge routing statistic table
		disp	display bridge route counter
		clear	clear bridge route counter
	stat		related to bridge packet statistic table
		disp	display bridge route packet counter
		clear	clear bridge route packet counter