ZyXEL Prestige 1.51(L.01)

Release Note/Manual Supplement

Date: June 11, 1999

This document describes the enhancements in the ZyXEL Prestige product line since the last manual printing. The bug fixes section describes problems corrected since version 1.50.

Bug fixes

Ver 1.51(L.01) (1999/6/11)
1. Fix bug: When SUA = Yes, ping to remote client does not work.

Ver 1.51 (1999/3/16)

1. CHAP used to fail if the length of password exceeds 15 characters. It is fixed.
2. Prestige used to report Error message: "SUA O/G: No port for source ...." for no good reason. It is fixed in this version.
3. Prestige used to report 0 for both of the ISDN iface inUnicast and outUnicast counters. Prestige reports the right value for inUnicast, outUnicast, ifSpeed and ifLastChange now.
4. In very large IPX networks, you might have problems accessing the desired servers. It is fixed in this release.
5. In v1.50, user had to drop the connection manually in order to placing a call successfully after unpluging/pluging the ISDN cable in a quick succession. It is fixed.

Known Problem List

1. Prestige has problems to support Unix remote commands (rlogin, rcp, and rsh) in SUA case.

To Upgrade Prestige

Get the files from ZyXEL anonymous FTP server (ftp.europe.zyxel.com). Upgrade your Prestige by following the instructions for your model:

```
Versions:
        RAS F/W Version  -      V1.51(L.01)  6/11/99
        ISDN F/W Version -      IDSL: V 082

RAS and ISDN firmware file:
        P128L.BIN ( for Prestige 128L only)

Commands:
        ATBAx:  Where x = baud rate
                options available are:
                        1= 38.4K
                        2= 19.2K
                        3= 9.6K
                        4= 57.6K
                        5= 115.2K
        ATUR:  Upload Firmware file via XMODEM
```

Romfile: "P128L.ROM" (also possible: ROMFILE0)
ATUR3: Upload Romfile and clear all settings
Note: You don't need to upload this file if you are upgrading from release 1.2(b.01) unless you want to reset all configurations to factory default.